

**Period: 2010-08-27 - 2010-08-30**

Date	Process	PP Code	Product Type	Brand	Fit Model	Replace Code	Others
2010/8/27	Admend	CL4237S	Battery	TOSHIBA	mini NB205-N310/BN-G, mini NB205-N323BL, mini NB205-N323BN, mini NB205-N324BL, mini NB205-N324WH, mini NB205-N325BL, mini NB205-N325BN, mini NB205-N325PK, mini NB205-N325WH, mini NB205-N330BL, mini NB205-N330BN, mini NB205-N330PK, mini NB205-N330WH, NB200-11M, NB200-11N, NB200-125, NB200-126, NB200-12N, NB200-12R, NB200-12V, NB200-12W		Category: UMPC, NetBook & MID
2010/8/27	Admend	CL4238B	Battery	TOSHIBA	mini NB200-12N, mini NB200-12R, mini NB205-N230, mini NB205-N313/P, mini NB255-N240, mini NB255-N245, mini NB255-N246, mini NB255-N250, NB200-00E, NB200-123, NB200-12U, NB200-131, NB200-13L, NB250-107, NB250-108, NB250-10G		Category: Laptop

2010/8/27	Admend	CL4238S	Battery	TOSHIBA	mini NB205-312, mini NB205-N211, mini NB205-N230, mini NB205-N310/BN-G, mini NB205-N311, mini NB205-N313P, mini NB205-N323BL, mini NB205-N323BN, mini NB205-N324BL, mini NB205-N324WH, mini NB205-N325BL, mini NB205-N325BN, mini NB205-N325PK, mini NB205-N325WH, mini NB205-N330BL, mini NB205-N330BN, mini NB205-N330PK, mini NB205-N330WH, NB200-11M, NB200-11N, NB200-125, NB200-126, NB200-12N, NB200-12R, NB200-12V, NB200-12W		Category: Laptop
2010/8/27	Add	CL1397B	Battery	ACER	Aspire One 531h-0BGk 3G, Aspire One 531h-0DGk 3G, Aspire One 531h-1729, Aspire One 531h-1D, Aspire One 531h-1DbB, Aspire One 531h-1DrB, Aspire One 531h-MCK11, Aspire One 531h-MCB11		Category: UMPC, NetBook & MID
2010/8/27	Add	CL1397B	Battery	ACER		LC.BTP00.070, LC.BTP00.071	Category: UMPC, NetBook & MID
2010/8/27	Add	PL826B	Battery	CANON	EOS 60D		Category: Digital Camera Related Products: AVNS826, ACMPB826, AVCP826, AVMP826
2010/8/27	Add	C7	Connector Tips	MICRON (MPC)	Millenia Transport, Millenia Transport 133, Transport MRX, Transport XPE, Trek 233 Series		Category: Laptop Related Products: AC090.008C7, DC091.006C7, DC090.006C7, AC090X.008, EL1901, EL1691, EL1692,
2010/8/27	Add	CL4363B	Battery	TOSHIBA	Satellite L650-02B		Category: Laptop
2010/8/27	Add	CL4566B	Battery	TOSHIBA	Satellite L650-02B		Category: Laptop

2010/8/27	Add	C7	Connector Tips	MICRON (MPC)	Millenia Transport, Millenia Transport 133, Transport MRX, Transport XPE, Trek 233 Series	Category: Laptop Related Products: AC060.011C7, AC080.011C7, AC080.011, DC091.005C7, DC120.002C7, DC090.005C7, AC060X.011, AC080X.011, EL1901, EL1691, EL1692, EL1695, EL1696
2010/8/27	Delete	C7	Connector Tips	MICRON (MPC)	Millenia Transport, Millenia Transport 133, Transport MRX, Transport XPE, Trek 233 Series	Category: Laptop Related Products: AC090.008C7, DC091.006C7, DC090.006C7, AC090X.008, EL1901, EL1691, EL1692, EL1695, EL1696
2010/8/30	Add	PL153B	Battery	SONY	Cyber-Shot DSC-W370, MHS-PM5 Series	Category: Digital Camera Related Products: AVNS152, AVEP152, AVCP152, ACMPB152, AVMP152
2010/8/30	Amend	PL153B	Battery			Remark: -> Not compatible with MHS-PM5 Series & DSC-W370

2010/8/30	Add	CL4529B	Battery	TOSHIBA	<p>Qosmio X500, Qosmio X500-116, Qosmio X500-11M, Qosmio X500-128, Qosmio X500-134, Qosmio X500-148, Qosmio X505, Qosmio X505-Q862, Qosmio X505-Q865, Qosmio X505-Q875, Qosmio X505-Q879, Qosmio X505-Q882, Qosmio X505-Q885, Qosmio X505-Q887, Qosmio X505-Q888, Qosmio X505-Q890, Satellite P500-12D, Satellite P500-12F, Satellite P500-14L, Satellite P500-1CG, Satellite P500-1DT, Satellite P500-1DW, Satellite P500-1DX, Satellite P500-1DZ, Satellite P500-1F8, Satellite P500-ST2G01, Satellite P500-ST5806, Satellite P500-ST5807, Satellite P500-ST6822, Satellite P500-ST6844, Satellite P505-S8002, Satellite P505-S8010, Satellite P505-S8011, Satellite P505-S8020, Satellite P505-S8022, Satellite P505-S8025, Satellite P505-S8970, Satellite P505-S8971, Satellite P505-S8980, Satellite P505D-S8000, Satellite P505D-S8005, Satellite P505D-S8007, Satellite P505D-S8960</p>		Category: Laptop
2010/8/30	Add	CL4530B	Battery	TOSHIBA	<p>Qosmio X500, Qosmio X505, Satellite P500-ST2G01, Satellite P500-ST5806, Satellite P500-ST5807, Satellite P500-ST6822, Satellite P500-ST6844, Satellite P505-S8002, Satellite P505-S8010, Satellite P505-S8011, Satellite P505-S8020, Satellite P505-S8022, Satellite P505-S8025, Satellite P505-S8970, Satellite P505-S8971, Satellite P505-S8980, Satellite P505D-S8000, Satellite P505D-S8005, Satellite P505D-S8007, Satellite P505D-S8960</p>		Category: Laptop

2010/8/30	New Product	ACP605	Charger Plate				
2010/8/30	New Product	PL351.334	Battery	SONY			
2010/8/30	New Product	ACMPB605A	Battery Charger	JVC			
2010/8/30	New Product	ACMPB605E	Battery Charger	JVC			
2010/8/30	New Product	ACMPB605H	Battery Charger	JVC			
2010/8/30	New Product	ACMPB605L	Battery Charger	JVC			
2010/8/30	New Product	ACMPB605Z	Battery Charger	JVC			
2010/8/30	New Product	AVCP605AZ	Battery Charger	JVC			
2010/8/30	New Product	AVCP605EZ	Battery Charger	JVC			
2010/8/30	New Product	AVCP605KZ	Battery Charger	JVC			
2010/8/30	New Product	AVCP605LZ	Battery Charger	JVC			
2010/8/30	New Product	AVCP605A	Battery Charger	JVC			
2010/8/30	New Product	AVCP605E	Battery Charger	JVC			
2010/8/30	New Product	AVCP605K	Battery Charger	JVC			
2010/8/30	New Product	AVCP605L	Battery Charger	JVC			
2010/8/30	Add	CL2873B	Battery	ACER		UM08B32	Category: UMPC, NetBook & MID
2010/8/30	Add	BL6100B	Battery	NOKIA	7705 Twist	CEX2-00	Category: Mobile Phone
2010/8/30	Delete	BL6100B	Battery	NOKIA	7705 Twist		Category: Mobile Phone
2010/8/30	New Product	CLX7452B.080	Battery	LENOVO			
2010/8/30	New Product	CLX7452B.083	Battery	LENOVO			
2010/8/30	New Product	CLX7452B.085	Battery	LENOVO			
2010/8/30	New Product	CL7452B.080	Battery	LENOVO			

2010/8/30	New Product	CL7452B.082	Battery	LENOVO			
2010/8/30	New Product	CL7452B.083	Battery	LENOVO			
2010/8/30	New Product	CL7452B.085	Battery	LENOVO			
2010/8/30	New Product	CL7452B.086	Battery	LENOVO			
2010/8/30	New Product	CL7452B.087	Battery	LENOVO			
2010/8/30	New Product	CL3768B.082	Battery	DELL			
2010/8/30	New Product	CL3768B.083	Battery	DELL			
2010/8/30	New Product	CL3768B.086	Battery	DELL			
2010/8/30	New Product	CL3768B.080	Battery	DELL			
2010/8/30	New Product	CL3768B.087	Battery	DELL			
2010/8/30	New Product	CL3768B.085	Battery	DELL			
2010/8/30	New Product	CL3769B.082	Battery	DELL			
2010/8/30	New Product	CL3769B.080	Battery	DELL			
2010/8/30	New Product	CL3769B.085	Battery	DELL			
2010/8/30	New Product	CL3769B.087	Battery	DELL			
2010/8/30	New Product	CL3769B.083	Battery	DELL			
2010/8/30	New Product	CL3769B.086	Battery	DELL			
2010/8/30	New Product	TB2417U.32H	Battery	MAKITA			
2010/8/30	Add	CL1848B	Battery	COMPAQ	Presario CQ50-200, Presario CQ60, Presario CQ60-100, Presario CQ60-200, Presario CQ60-300, Presario CQ60-400, Presario CQ61-100, Presario CQ61-200, Presario CQ61-300		Category: Laptop

2010/8/30	Add	CL1848B	Battery	HP	G60, G60-100, G60-100 CTO, G60-100EM, G60-101CA, G60-101TU, G60-102XX, G60-103XX, G60-104CA, G60-104XX, G60-108CA, G60-114EA, G60-115EA, G60-115EM, G60-116EA, G60-116EM, G60-117EM, G60-117US, G60-118EM, G60-118NR, G60-119EA, G60-119EM, G60-119OM, G60-120CA, G60-120EM, G60-120US, G60-121CA, G60-121WM, G60-123CL, G60-125CA, G60-125NR, G60-126CA, G60-127CL, G60-127NR, G60-128CA, G60-129CA, G60-146CA, G60-200, G60-201TU, G60-202TU, G60-203TU, G60-208CA, G60-213EM, G60-214EM, G60-215EM, G60-216EM, G60-217EM, G60-219CA, G60-219EA, G60-225CA, G60-228CA, G60-230CA, G60-230US, G60-231WM, G60-233CA, G60-233NR, G60-234CA, G60-235CA, G60-235DX, G60-235WM, G60-236US, G60-237NR, G60-237US, G60-238CA, G60-243CL, G60-243DX, G60-244DX, G60-247CL, G60-249CA, G60-249WM, G60-300, G60-304CA, G60-324CA, G60-348CA, G60-400, G60-414CA, G60-418CA, G60-427CA, G60-428CA, G60-430CA,		Category: Laptop
-----------	-----	---------	---------	----	---	--	------------------

					<p>G60-433CA, G60-437CA, G60-438NR, G60-439CA, G60-440US, G60-441US, G60-442OM, G60-443CL, G60-443NR, G60-445DX, G60-447CL, G60-453NR, G60-458DX, G60-468CA, G60-471NR, G60-500, G60-501NR, G60-506US, G60-507DX, G60-508US, G60-511CA, G60-513NR, G60-519WM, G60-526NR, G60-530CA, G60-530US, G60-531CA, G60-531NR, G60-533CL, G60-535DX, G60-536NR, G60-538CA, G60-549DX, G60-550CA, G60-551CA, G60-552NR, G60-553NR, G60-554CA, G60-600, G60-610CA, G60-619CA, G60-630CA, G60-630US, G60-633NR, G60-634CA, G60-635DX, G60-637CL, G60-642NR, G60-645NR, G60-647NR, G60-657CA, G60T-200 CTO, G60t-500 CTO, G60t-600 CTO, G61-300, G61-400, G70-400, G71-300, HDX X16-1000 Premium, HDX X16-1100 Premium, HDX X16-1200 Premium, HDX X16-1300 Premium, HDX X18-1100 Premium, HDX X18-1200 Premium, HDX X18-1300 Premium, Pavilion dv4-1300, Pavilion dv4-1400, Pavilion dv4-1500, Pavilion dv4-2000, Pavilion dv4-2100, Pavilion dv5-1200, Pavilion dv5-1300, Pavilion dv8-1000</p>		
2010/8/30	Add	CL1848B	Battery	HP		462890-421, 462891-141	Category: Laptop
2010/8/30	Add	CL1847B	Battery	COMPAQ	<p>Presario CQ50-200, Presario CQ60, Presario CQ60-100, Presario CQ60-200, Presario CQ60-300, Presario CQ60-400, Presario CQ61-100, Presario CQ61-200, Presario CQ61-300</p>		Category: Laptop

2010/8/30	Add	CL1847B	Battery	HP	G60, G60-100, G60-100 CTO, G60-100EM, G60-101CA, G60-101TU, G60-102XX, G60-103XX, G60-104CA, G60-104XX, G60-108CA, G60-114EA, G60-115EA, G60-115EM, G60-116EA, G60-116EM, G60-117EM, G60-117US, G60-118EM, G60-118NR, G60-119EA, G60-119EM, G60-119OM, G60-120CA, G60-120EM, G60-120US, G60-121CA, G60-121WM, G60-123CL, G60-125CA, G60-125NR, G60-126CA, G60-127CL, G60-127NR, G60-128CA, G60-129CA, G60-146CA, G60-200, G60-201TU, G60-202TU, G60-203TU, G60-208CA, G60-213EM, G60-214EM, G60-215EM, G60-216EM, G60-217EM, G60-219CA, G60-219EA, G60-225CA, G60-228CA, G60-230CA, G60-230US, G60-231WM, G60-233CA, G60-233NR, G60-234CA, G60-235CA, G60-235DX, G60-235WM, G60-236US, G60-237NR, G60-237US, G60-238CA, G60-243CL, G60-243DX, G60-244DX, G60-247CL, G60-249CA, G60-249WM, G60-300, G60-304CA, G60-324CA, G60-348CA, G60-400, G60-414CA, G60-418CA, G60-427CA, G60-428CA, G60-430CA,	Category: Laptop
-----------	-----	---------	---------	----	---	------------------

					G60-433CA, G60-437CA, G60-438NR, G60-439CA, G60-440US, G60-441US, G60-442OM, G60-443CL, G60-443NR, G60-445DX, G60-447CL, G60-453NR, G60-458DX, G60-468CA, G60-471NR, G60-500, G60-501NR, G60-506US, G60-507DX, G60-508US, G60-511CA, G60-513NR, G60-519WM, G60-526NR, G60-530CA, G60-530US, G60-531CA, G60-531NR, G60-533CL, G60-535DX, G60-536NR, G60-538CA, G60-549DX, G60-550CA, G60-551CA, G60-552NR, G60-553NR, G60-554CA, G60-600, G60-610CA, G60-619CA, G60-630CA, G60-630US, G60-633NR, G60-634CA, G60-635DX, G60-637CL, G60-642NR, G60-645NR, G60-647NR, G60-657CA, G60T-200 CTO, G60t-500 CTO, G60t-600 CTO, G61-300, G61-400, G70-400, G71-300, HDX X16-1000 Premium, HDX X16-1100 Premium, HDX X16-1200 Premium, HDX X16-1300 Premium, HDX X18-1100 Premium, HDX X18-1200 Premium, HDX X18-1300 Premium, Pavilion dv4-1300, Pavilion dv4-1400, Pavilion dv4-1500, Pavilion dv4-2000, Pavilion dv4-2100, Pavilion dv5-1200, Pavilion dv5-1300, Pavilion dv8-1000		
2010/8/30	Add	CL1847B	Battery	HP		462890-421	Category: Laptop
2010/8/30	Add	PL140B	Battery	PENTAX	Optio M900, Optio M90	D-LI108	Category: Digital Camera Related Products: AVCP140, AVEP140, AVMP140, AVNS140, ACMPB140
2010/8/30	New Product	TB1420B.32H	Battery	MAKITA			
2010/8/30	New Product	TB1220B.32H	Battery	MAKITA			

2010/8/30	Amend	FR123U	Battery				Remark: -> This battery may be used for most small electronic devices such as film cameras, digital cameras, night-vision scopes, binoculars, LED flashlight, shavers,...etc., except battery-operated torch with tungsten bulb, or any other devices with a tungsten heating/lighting
2010/8/30	Amend	CL3385B.085	Battery				Rate: -> 80 Wh